



## Primary Panel

The primary panel option allows any of the display images to be set as the primary image.

**Axial:** Makes the axial image the primary image. [1]

**Coronal:** Makes the coronal image the primary image.

**Sagittal:** Makes the sagittal image the primary image.

**Oblique:** Available when the Oblique option is selected. Makes the oblique image the primary image.

**3-D:** Makes the current selected 3-D display the primary image.

