



Primary Panel

The primary panel option allows any of the display images to be set as the primary image.

Axial: Makes the axial image the primary image. [1]

Coronal: Makes the coronal image the primary image.

Sagittal: Makes the sagittal image the primary image.

Oblique: Available when the Oblique option is selected. Makes the oblique image the primary image.

3-D: Makes the current selected 3-D display the primary image.

